

Nummer	Instrument	Gruppe	Bank	Programm
1	22Accordion	Accordion	0	21
2	23Harmonica	Accordion	0	22
3	24Accordion	Accordion	0	23
4	60AccVM	Accordion	53	59
5	61AccVM	Accordion	53	60
6	62AccVM	Accordion	53	61
7	63AccZup	Accordion	53	62
8	64AccVM	Accordion	53	63
9	66AccZup	Accordion	53	65
10	01Gol888	Accordion	71	0
11	02Gol888/16	Accordion	71	1
12	05Vm888	Accordion	71	4
13	06Vm888/16	Accordion	71	5
14	09JShand 888	Accordion	71	8
15	10JShand 88816	Accordion	71	9
16	13Irish888	Accordion	71	12
17	14Irish88816	Accordion	71	13
18	17Irish88	Accordion	71	16
19	18Irish8816	Accordion	71	17
20	19Irish4-88	Accordion	71	18
21	20Irish48816	Accordion	71	19
22	21Irish8"	Accordion	71	20
23	22Irish816	Accordion	71	21
24	23Irish48	Accordion	71	22
25	24Irish4816	Accordion	71	23
26	25V3 8+88 wide	Accordion	71	24
27	26V3 8+88 wide dark	Accordion	71	25
28	27V3 8+88+8 wide	Accordion	71	26
29	28V3 8+88 small	Accordion	71	27
30	33Reed16	Accordion	71	32
31	34Reed4"	Accordion	71	33
32	35IrishMelo88	Accordion	71	34
33	36 8+8tune small	Accordion	71	35
34	37 8+8tune medium	Accordion	71	36
35	38 8+8tune wide	Accordion	71	37
36	39 8+Acc8tune small	Accordion	71	38
37	40 8+Acc8tune med.	Accordion	71	39
38	41 8+Acc8tune wide	Accordion	71	40
39	01French 88	Accordion	72	0
40	02Tango	Accordion	72	1
41	10ZuAlpin 8 Reed	Accordion	72	9
42	11ZuAlpin 8+8 med.	Accordion	72	10
43	12ZuAlpin 8+8 flat	Accordion	72	11
44	13ZuAlpin 8+8 small	Accordion	72	12
45	14ZuAlpin 8+8 wide	Accordion	72	13
46	15ZuAlpin 8+16	Accordion	72	14
47	16ZuAlpin 4	Accordion	72	15
48	01V3Vintage 888	Accordion	80	0
49	02Vintage 88816	Accordion	80	1
50	03Vintage 4888	Accordion	80	2
51	04Vintage 488816	Accordion	80	3

Nummer	Instrument	Gruppe	Bank	Programm
52	10Vintage 888	Accordion	80	9
53	11Krain888	Accordion	80	10
54	12V3Krain88816	Accordion	80	11
55	13Krain4888	Accordion	80	12
56	14Krain488816	Accordion	80	13
57	20Krain888	Accordion	80	19
58	21V3Alpina888"	Accordion	80	20
59	22Alpina88816	Accordion	80	21
60	23Alpina4888	Accordion	80	22
61	24Alpina488816	Accordion	80	23
62	25Alpina.888dy	Accordion	80	24
63	30Alpina888	Accordion	80	29
64	51Juwel88	Accordion	80	50
65	52Juwel8816	Accordion	80	51
66	53Juwel488	Accordion	80	52
67	54Juwel48816	Accordion	80	53
68	60Juwel 88	Accordion	80	59
69	61Bugari16	Accordion	80	60
70	62Bugari16	Accordion	80	61
71	63Bugari416	Accordion	80	62
72	64Bugari816	Accordion	80	63
73	65Zupan8	Accordion	80	64
74	69Scand816	Accordion	80	68
75	70Scand816	Accordion	80	69
76	101Bass	Accordion Bässe&Chord	80	100
77	102Bass 16	Accordion Bässe&Chord	80	101
78	103Bass 8	Accordion Bässe&Chord	80	102
79	104Bass 4	Accordion Bässe&Chord	80	103
80	105Bass 2	Accordion Bässe&Chord	80	104
81	106Bass 16+8	Accordion Bässe&Chord	80	105
82	107Bass 16+8+4	Accordion Bässe&Chord	80	106
83	109VlChord	Accordion Bässe&Chord	80	108
84	110Chord 4	Accordion Bässe&Chord	80	109
85	111Chord 8	Accordion Bässe&Chord	80	110
86	112Chord 4+8	Accordion Bässe&Chord	80	111
87	113Chord 2+4	Accordion Bässe&Chord	80	112
88	114Steirische Bass	Accordion Bässe&Chord	80	113
89	115Steirische Bass 2	Accordion Bässe&Chord	80	114
90	116Steir. Akk.	Accordion Bässe&Chord	80	115
91	121Helikon	Accordion Bässe&Chord	80	120
92	122Helikoncc57	Accordion Bässe&Chord	80	121
93	123Key OFF	Accordion Bässe&Chord	80	122
94	124Attack Layer linear	Accordion Bässe&Chord	80	123
95	125Attack Layer concave	Accordion Bässe&Chord	80	124
96	126Attack Layer con. offset 50	Accordion Bässe&Chord	80	125
97	78 Acc888 Musette	Accordion Benelux	72	77
98	79 Acc888+8 Musette Exm	Accordion Benelux	72	78
99	17MauMusette 888	Accordion French	72	16
100	21Ho88	Accordion French	72	20
101	23Tango8+16	Accordion French	72	22
102	24Tango4816	Accordion French	72	23

Nummer	Instrument	Gruppe	Bank	Programm
103	25Celest88	Accordion French	72	24
104	42CavVintage 8 Reed	Accordion French	72	41
105	07Alpina888 mono	Accordion Helikon	26	6
106	08Alpina888 weich mono	Accordion Helikon	26	7
107	09Alp888stc.	Accordion Helikon	26	8
108	10AccMorR16	Accordion Helikon	26	9
109	11AccMor16	Accordion Helikon	26	10
110	12Acc.MOR.4´	Accordion Helikon	26	11
111	15Acc.MOR.88	Accordion Helikon	26	14
112	17Acc.MOR88 mono 2	Accordion Helikon	26	16
113	18Acc.88´staccato	Accordion Helikon	26	17
114	19Acc.MOR.8´	Accordion Helikon	26	18
115	20Acc.MOR.4/16´	Accordion Helikon	26	19
116	21Acc.MOR.4/88´	Accordion Helikon	26	20
117	22Acc.88/16´	Accordion Helikon	26	21
118	23Morino816	Accordion Helikon	26	22
119	24Alpina88816	Accordion Helikon	26	23
120	25Alpina4888	Accordion Helikon	26	24
121	26AlpinaV	Accordion Helikon	26	25
122	27Alpina ix	Accordion Helikon	26	26
123	28Akk88	Accordion Helikon	26	27
124	29Akk816	Accordion Helikon	26	28
125	34Steirische26a	Accordion Helikon	26	33
126	35Steirische26b	Accordion Helikon	26	34
127	38Orgeli262	Accordion Helikon	26	37
128	39Orgeli263	Accordion Helikon	26	38
129	40Musette261	Accordion Helikon	26	39
130	41Musette262	Accordion Helikon	26	40
131	42Musette263	Accordion Helikon	26	41
132	43Musette264	Accordion Helikon	26	42
133	44French	Accordion Helikon	26	43
134	45Helikon261	Accordion Helikon	26	44
135	46Helikon262	Accordion Helikon	26	45
136	47HelikonStc.	Accordion Helikon	26	46
137	53OrgeliBass	Accordion Helikon	26	52
138	82HoCorso 888	Accordion Ho Wem	72	81
139	83Wem8 Reed	Accordion Ho Wem	72	82
140	84Wem8+8 small	Accordion Ho Wem	72	83
141	85Wem8+8 medium	Accordion Ho Wem	72	84
142	86Wem8+8 wide	Accordion Ho Wem	72	85
143	87Wem8+8+8 small	Accordion Ho Wem	72	86
144	88Wem8+8+8 medium	Accordion Ho Wem	72	87
145	89Wem8+8+8 wide	Accordion Ho Wem	72	88
146	90Wem888	Accordion Ho Wem	72	89
147	91Wem888+8	Accordion Ho Wem	72	90
148	92Wem8+16	Accordion Ho Wem	72	91
149	93Bandonium	Accordion Ho Wem	72	92
150	95Accordina	Accordion Ho Wem	72	94
151	48Sca8	Accordion Italien	72	47
152	49Sca88	Accordion Italien	72	48
153	50Sca8+8 flat	Accordion Italien	72	49

Nummer	Instrument	Gruppe	Bank	Programm
154	51Sca8+8 flat+	Accordion Italien	72	50
155	52Sca8+8 medium	Accordion Italien	72	51
156	53Sca8+8+8 medium	Accordion Italien	72	52
157	54Sca8+8+8 wide	Accordion Italien	72	53
158	55Sca8+8+8 wide +	Accordion Italien	72	54
159	66Bug16 Reed	Accordion Italien	72	65
160	67Men888 Retro Musette	Accordion Italien	72	66
161	68Bam8 Reed Spc	Accordion Italien	72	67
162	69Bam+SCVI 8+8Exm	Accordion Italien	72	68
163	70Bam +SCVI 8+8Exm	Accordion Italien	72	69
164	71Ho4+8+16	Accordion Italien	72	70
165	72Ho4+8+8+16	Accordion Italien	72	71
166	73Ho8+8	Accordion Italien	72	72
167	01Alpina888	Accordion Musett Steir	30	0
168	02Alpina888	Accordion Musett Steir	30	1
169	03Alpina888	Accordion Musett Steir	30	2
170	04Alpina888	Accordion Musett Steir	30	3
171	05Alpina888	Accordion Musett Steir	30	4
172	06Alpina888	Accordion Musett Steir	30	5
173	07Alpina888	Accordion Musett Steir	30	6
174	08Alpina888	Accordion Musett Steir	30	7
175	09Alpina888	Accordion Musett Steir	30	8
176	10Akk16	Accordion Musett Steir	30	9
177	11Acc16	Accordion Musett Steir	30	10
178	12Acc16	Accordion Musett Steir	30	11
179	13Acc4	Accordion Musett Steir	30	12
180	14Acc416	Accordion Musett Steir	30	13
181	15Acc88	Accordion Musett Steir	30	14
182	16Acc88	Accordion Musett Steir	30	15
183	17Acc88	Accordion Musett Steir	30	16
184	18Acc88	Accordion Musett Steir	30	17
185	19Acc8	Accordion Musett Steir	30	18
186	20Acc488	Accordion Musett Steir	30	19
187	21Acc8816	Accordion Musett Steir	30	20
188	22Acc816	Accordion Musett Steir	30	21
189	23Acc88816	Accordion Musett Steir	30	22
190	24Acc816	Accordion Musett Steir	30	23
191	25Alp+Diaton	Accordion Musett Steir	30	24
192	26Steirische	Accordion Musett Steir	30	25
193	27Steirische	Accordion Musett Steir	30	26
194	28Steirische	Accordion Musett Steir	30	27
195	29Steirische	Accordion Musett Steir	30	28
196	30Steirische	Accordion Musett Steir	30	29
197	31Steirische	Accordion Musett Steir	30	30
198	32Steirische	Accordion Musett Steir	30	31
199	33Steirische	Accordion Musett Steir	30	32
200	34Musette888	Accordion Musett Steir	30	33
201	35Musette88816	Accordion Musett Steir	30	34
202	36Musettella	Accordion Musett Steir	30	35
203	37Musettelllb	Accordion Musett Steir	30	36
204	38VM888 1	Accordion Musett Steir	30	37

Nummer	Instrument	Gruppe	Bank	Programm
205	39VM888 2	Accordion Musett Steir	30	38
206	40VM888 3	Accordion Musett Steir	30	39
207	41VM888/16	Accordion Musett Steir	30	40
208	42VM 4	Accordion Musett Steir	30	41
209	43Krainer 4	Accordion Musett Steir	30	42
210	44Krainer 8	Accordion Musett Steir	30	43
211	45Krainer 16	Accordion Musett Steir	30	44
212	46Krainer 16	Accordion Musett Steir	30	45
213	47Musette 888	Accordion Musett Steir	30	46
214	48Harmonika	Accordion Musett Steir	30	47
215	49Harmonika	Accordion Musett Steir	30	48
216	50Alpina 888	Accordion Musett Steir	30	49
217	51Harmonika	Accordion Musett Steir	30	50
218	52Harmonika	Accordion Musett Steir	30	51
219	53Harmonika	Accordion Musett Steir	30	52
220	54Harmonika	Accordion Musett Steir	30	53
221	55Harmonika	Accordion Musett Steir	30	54
222	56Harmonika	Accordion Musett Steir	30	55
223	57Alpengold	Accordion Musett Steir	30	56
224	58Alpengold	Accordion Musett Steir	30	57
225	59Alpengold	Accordion Musett Steir	30	58
226	60Harmonika	Accordion Musett Steir	30	59
227	61Akk 88	Accordion Musett Steir	30	60
228	62Akk 888	Accordion Musett Steir	30	61
229	63Krainer HPF	Accordion Musett Steir	30	62
230	64Steirische	Accordion Musett Steir	30	63
231	65Steirische	Accordion Musett Steir	30	64
232	66Orgeli 2	Accordion Musett Steir	30	65
233	67Orgeli 3	Accordion Musett Steir	30	66
234	68Gola 88	Accordion Musett Steir	30	67
235	69Gola 816	Accordion Musett Steir	30	68
236	70KrainerHPF	Accordion Musett Steir	30	69
237	77HarmonikaDur	Accordion Musett Steir	30	76
238	78HarmonikaBass	Accordion Musett Steir	30	77
239	79HarmonikaHPF	Accordion Musett Steir	30	78
240	80HarmonikaBass 2	Accordion Musett Steir	30	79
241	81AccSilberbach	Accordion Musett Steir	30	80
242	82AccSilberbach	Accordion Musett Steir	30	81
243	83AccSilberbach	Accordion Musett Steir	30	82
244	84AccSilberbach	Accordion Musett Steir	30	83
245	85OrgeliBass	Accordion Musett Steir	30	84
246	95M-St. Leonhard	Accordion Steirische	80	94
247	98M-St. Leonhard	Accordion Steirische	80	97
248	06SuperVI	Accordion&Whistle	98	5
249	07Reed8	Accordion&Whistle	98	6
250	08Steirisch	Accordion&Whistle	98	7
251	09Alpengold	Accordion&Whistle	98	8
252	10Alpina	Accordion&Whistle	98	9
253	11ShandMusette	Accordion&Whistle	98	10
254	12Gola Musette	Accordion&Whistle	98	11
255	13Morino VM	Accordion&Whistle	98	12

Nummer	Instrument	Gruppe	Bank	Programm
256	14HighWhistle	Accordion&Whistle	98	13
257	15AccCeleste	Accordion&Whistle	98	14
258	16WM Melodeon	Accordion&Whistle	98	15
259	17Accordiona	Accordion&Whistle	98	16
260	19Alphörner	Alphorn	75	18
261	101Hackbrett Appenzeller"	Alpschellen Choir Synth Misch	23	100
262	102AlpenschellenHit	Alpschellen Choir Synth Misch	23	101
263	103AlpenschellenRoll	Alpschellen Choir Synth Misch	23	102
264	104ChoirSoftOoo	Alpschellen Choir Synth Misch	23	103
265	105SynthHookLine	Alpschellen Choir Synth Misch	23	104
266	106SynthPadOBX	Alpschellen Choir Synth Misch	23	105
267	107SynthPadOBXSoft	Alpschellen Choir Synth Misch	23	106
268	108SynthPadOBXWarm	Alpschellen Choir Synth Misch	23	107
269	109SynthPadOBX ENV	Alpschellen Choir Synth Misch	23	108
270	110DX1Bell oy	Alpschellen Choir Synth Misch	23	109
271	111DX1BellToyDelay	Alpschellen Choir Synth Misch	23	110
272	9Banjo	Banj Steel Marimba	24	8
273	10Steel Drums	Banj Steel Marimba	24	9
274	11Marimba	Banj Steel Marimba	24	10
275	41Bariton1	Bariton	52	40
276	45Bariton1kurz	Bariton	52	44
277	49Bariton2	Bariton	52	48
278	51Bariton2kurz	Bariton	52	50
279	53Bariton3Mega	Bariton	52	52
280	55Bariton3Magakurz	Bariton	52	54
281	57Bariton4	Bariton	52	56
282	61Bariton4kurz	Bariton	52	60
283	33CB-Bass	Bass	0	32
284	34E-Bass	Bass	0	33
285	35E-BassPick	Bass	0	34
286	36FretlessBass	Bass	0	35
287	37SlapBass	Bass	0	36
288	38SlapBass	Bass	0	37
289	39SynthBass	Bass	0	38
290	40SynthBasss	Bass	0	39
291	107KB gestrichen	Bass	26	106
292	109KB gezupft	Bass	26	108
293	63BassFretless	Bass & Brass	24	62
294	64BrassSection YT1	Bass & Brass	24	63
295	77PosauneBass	Bass Bari Synth Tuba	26	76
296	78Bariton	Bass Bari Synth Tuba	26	77
297	79Bariton	Bass Bari Synth Tuba	26	78
298	80Bariton stc.	Bass Bari Synth Tuba	26	79
299	81Bariton stc.	Bass Bari Synth Tuba	26	80
300	82Bariton	Bass Bari Synth Tuba	26	81
301	83Bariton	Bass Bari Synth Tuba	26	82
302	84BaritonStc.	Bass Bari Synth Tuba	26	83
303	85BaritonStc.	Bass Bari Synth Tuba	26	84
304	86Bariton	Bass Bari Synth Tuba	26	85
305	87CS01Synth	Bass Bari Synth Tuba	26	86
306	88CS01Synth	Bass Bari Synth Tuba	26	87

Nummer	Instrument	Gruppe	Bank	Programm
307	89DXSynthbass	Bass Bari Synth Tuba	26	88
308	90Tuba	Bass Bari Synth Tuba	26	89
309	91TubaStc26	Bass Bari Synth Tuba	26	90
310	92TubaSoft26	Bass Bari Synth Tuba	26	91
311	93TubaStac26	Bass Bari Synth Tuba	26	92
312	94Tuben26	Bass Bari Synth Tuba	26	93
313	50Bariton stc.	Bass Bariton	32	49
314	51Bariton staccato	Bass Bariton	32	50
315	52Bariton stac.C/Cis	Bass Bariton	32	51
316	53Bariton stac.C/Cis	Bass Bariton	32	52
317	54Bariton stac.fast	Bass Bariton	32	53
318	55Bariton stac.fast	Bass Bariton	32	54
319	56Bariton stac.fast C/Cis	Bass Bariton	32	55
320	57Bariton stac.fast C/Cis	Bass Bariton	32	56
321	58Bariton Akzent	Bass Bariton	32	57
322	59Bariton Akzent	Bass Bariton	32	58
323	60Bariton Akz.C/Cis	Bass Bariton	32	59
324	61Bariton Akz.C/Cis	Bass Bariton	32	60
325	62Bariton Akz.f C/Cis	Bass Bariton	32	61
326	63Bariton Akz.f C/Cis	Bass Bariton	32	62
327	64Bariton Vibrato	Bass Bariton	32	63
328	65*Bariton Vibrato C/Cis	Bass Bariton	32	64
329	66Bariton Vib.fast	Bass Bariton	32	65
330	67Bariton Vib.fast C/Cis	Bass Bariton	32	66
331	68Bariton Vibrato 2	Bass Bariton	32	67
332	69Bariton Vib.2 C/Cis	Bass Bariton	32	68
333	70Effekte Bariton	Bass Bariton	32	69
334	72Bariton2 Staccato	Bass Bariton	32	71
335	73Bariton2 stc. forte	Bass Bariton	32	72
336	74Bariton2 stc. mezzo	Bass Bariton	32	73
337	75Bariton2 stc. C/Cis	Bass Bariton	32	74
338	76Bariton2 stc.forte C/Cis	Bass Bariton	32	75
339	77Bariton2 stc.mezzo C/Cis	Bass Bariton	32	76
340	78Bariton2 marcato	Bass Bariton	32	77
341	79Bariton2 marc.forte	Bass Bariton	32	78
342	80Bariton2 marc.mezzo	Bass Bariton	32	79
343	81Bariton2 marc. C/Cis	Bass Bariton	32	80
344	82Bariton2 mrc.f C/Cis	Bass Bariton	32	81
345	83Bariton2 mrc.mz C/Cis	Bass Bariton	32	82
346	84Bariton Pedaltone	Bass Bariton	32	83
347	85Bariton3 staccato	Bass Bariton	32	84
348	86Bariton3 stc. fast	Bass Bariton	32	85
349	87Bariton3 stc. C/Cis	Bass Bariton	32	86
350	88Bariton3 stc. fast C/Cis	Bass Bariton	32	87
351	89Bariton3 stc. 2 C/Cis	Bass Bariton	32	88
352	90Bariton3 marcato	Bass Bariton	32	89
353	91Bariton3 marcato fast	Bass Bariton	32	90
354	92Bariton3 marcato C/Cis	Bass Bariton	32	91
355	93Bariton3 marc.fast C/Cis	Bass Bariton	32	92
356	94Bariton3 marc.2 C/Cis	Bass Bariton	32	93
357	95Bassposaune stc. 1	Bass Bariton	32	94

Nummer	Instrument	Gruppe	Bank	Programm
358	96Bassposaune stc. 2	Bass Bariton	32	95
359	97Bassposaune marc. 1	Bass Bariton	32	96
360	98Bassposaune marc. 2	Bass Bariton	32	97
361	99Basspos. marc.fast 1	Bass Bariton	32	98
362	100Basspos. marc. fast 2	Bass Bariton	32	99
363	101Basspos. & Sub	Bass Bariton	32	100
364	103Tuba staccato	Bass Bariton	32	102
365	104Tuba marcato	Bass Bariton	32	103
366	105Tuba soft	Bass Bariton	32	104
367	109BaritonStc.	Bass Bariton Tuba	31	108
368	110BaritonAkzent	Bass Bariton Tuba	31	109
369	111BaritonVibrato	Bass Bariton Tuba	31	110
370	112Bariton2Stc.	Bass Bariton Tuba	31	111
371	113Bariton2Akzent	Bass Bariton Tuba	31	112
372	122TubaStc.	Bass Bariton Tuba	31	121
373	123TubaMarcato	Bass Bariton Tuba	31	122
374	124TubaSoft	Bass Bariton Tuba	31	123
375	01E-Bass1	Bass EBass&Kontra	32	0
376	02E-Bass1C/Cis	Bass EBass&Kontra	32	1
377	03E-Bass1Es/E	Bass EBass&Kontra	32	2
378	04E-Bass2	Bass EBass&Kontra	32	3
379	05E-Bass2C/Cis	Bass EBass&Kontra	32	4
380	06E-Bass2Es/E	Bass EBass&Kontra	32	5
381	07E-Bass3	Bass EBass&Kontra	32	6
382	08E-Bass3C/Cis	Bass EBass&Kontra	32	7
383	09E-Bass3Es/E	Bass EBass&Kontra	32	8
384	10E-Bass4	Bass EBass&Kontra	32	9
385	11E-Bass4C/Cis	Bass EBass&Kontra	32	10
386	12E-Bass4Es/E	Bass EBass&Kontra	32	11
387	13E-Bass5	Bass EBass&Kontra	32	12
388	14E-Bass5C/Cis	Bass EBass&Kontra	32	13
389	15E-Bass5Es/E	Bass EBass&Kontra	32	14
390	16E-Bass6	Bass EBass&Kontra	32	15
391	17E-Bass6C/Cis	Bass EBass&Kontra	32	16
392	18E-Bass6Es/E	Bass EBass&Kontra	32	17
393	19E-BassSub	Bass EBass&Kontra	32	18
394	20E-BassSubC/Cis	Bass EBass&Kontra	32	19
395	21E-BassSubEs/E	Bass EBass&Kontra	32	20
396	23KontrabWeich 1	Bass EBass&Kontra	32	22
397	24KontrabWeich 2	Bass EBass&Kontra	32	23
398	25KontrabWeich 3	Bass EBass&Kontra	32	24
399	26KontrabC/Ciswe2	Bass EBass&Kontra	32	25
400	27KontrabC/Cis we3	Bass EBass&Kontra	32	26
401	28KontrabEs/E we2	Bass EBass&Kontra	32	27
402	29KontrabEs/E we3	Bass EBass&Kontra	32	28
403	30KontrabF/Fis we2	Bass EBass&Kontra	32	29
404	31KontrabF/Fis we3	Bass EBass&Kontra	32	30
405	32KontrabWalzer 1	Bass EBass&Kontra	32	31
406	33KontrabWalzer 2	Bass EBass&Kontra	32	32
407	34KontrabWalzer 3	Bass EBass&Kontra	32	33
408	35KontrabC/Cis wa2	Bass EBass&Kontra	32	34

Nummer	Instrument	Gruppe	Bank	Programm
409	36KontrabC/Cis wa3	Bass EBass&Kontra	32	35
410	37KontrabEs/E wa2	Bass EBass&Kontra	32	36
411	38KontrabEs/E wa3	Bass EBass&Kontra	32	37
412	39KontrabF/Fis wa2	Bass EBass&Kontra	32	38
413	40KontrabF/Fis wa3	Bass EBass&Kontra	32	39
414	41KontrabStaccato 1	Bass EBass&Kontra	32	40
415	42KontrabStaccato 2	Bass EBass&Kontra	32	41
416	43KontrabStaccato 3	Bass EBass&Kontra	32	42
417	44KontrabC/Cis st2	Bass EBass&Kontra	32	43
418	45Kontrab. C/Cis st3	Bass EBass&Kontra	32	44
419	46Kontrab. Jazz	Bass EBass&Kontra	32	45
420	47*Kontrabass Jazz Es/E	Bass EBass&Kontra	32	46
421	01E-BassUSA	Bass E-Bässe	82	0
422	02E-BassUSA	Bass E-Bässe	82	1
423	03E-BassUSA EQ1	Bass E-Bässe	82	2
424	04E-BassUSA EQ1	Bass E-Bässe	82	3
425	05E-BassUSA EQ2	Bass E-Bässe	82	4
426	06E-BassUSA EQ2	Bass E-Bässe	82	5
427	09E-BassUSA EQ3	Bass E-Bässe	82	8
428	10E-BassUSA EQ3	Bass E-Bässe	82	9
429	13E-BassUK	Bass E-Bässe	82	12
430	14E-BassUK	Bass E-Bässe	82	13
431	17E-Bass	Bass E-Bässe	82	16
432	18E-BassPick	Bass E-Bässe	82	17
433	21E-BassPickEQ	Bass E-Bässe	82	20
434	22E-BassPickEQ	Bass E-Bässe	82	21
435	25E-BassFlat	Bass E-Bässe	82	24
436	26E-BassFlat	Bass E-Bässe	82	25
437	27E-BassFlatEQ	Bass E-Bässe	82	26
438	28E-BassFlatEQ	Bass E-Bässe	82	27
439	51Kontrabass T	Bass Kontrabässe	82	50
440	52Kontrabass T	Bass Kontrabässe	82	51
441	53Kontrabass T"	Bass Kontrabässe	82	52
442	54Kontrabass T	Bass Kontrabässe	82	53
443	57Kontrabass 2	Bass Kontrabässe	82	56
444	58Kontrabass 2	Bass Kontrabässe	82	57
445	61Kontrabass 3	Bass Kontrabässe	82	60
446	62Kontrabass 3	Bass Kontrabässe	82	61
447	63Kontrabass 3 soft	Bass Kontrabässe	82	62
448	64Kontrabass 3 soft	Bass Kontrabässe	82	63
449	71Kontrabass kurz	Bass Kontrabässe	82	70
450	72KB kurz	Bass Kontrabässe	82	71
451	73KB kurz	Bass Kontrabässe	82	72
452	74KB kurz	Bass Kontrabässe	82	73
453	81DX100 kurz	Bass Synthbässe	82	80
454	82DX100	Bass Synthbässe	82	81
455	83DX100 Reso	Bass Synthbässe	82	82
456	84DX100 HighPass	Bass Synthbässe	82	83
457	86CS25 Freddy kurz	Bass Synthbässe	82	85
458	87CS25 Freddy	Bass Synthbässe	82	86
459	88CS25 Freddy Reso	Bass Synthbässe	82	87

Nummer	Instrument	Gruppe	Bank	Programm
460	89CS25 Freddy HighPass	Bass Synthbässe	82	88
461	91CS01 kurz	Bass Synthbässe	82	90
462	92CS01	Bass Synthbässe	82	91
463	93CS01 Reso	Bass Synthbässe	82	92
464	95Zillertal 3 kurz	Bass Synthbässe	82	94
465	96Zillertal 3	Bass Synthbässe	82	95
466	97Zillertal 3b	Bass Synthbässe	82	96
467	107Bb-Tuba	Bass Tuba D-Bass	32	106
468	108Tuben Mix	Bass Tuba D-Bass	32	107
469	109CE25 staccato	Bass Tuba D-Bass	32	108
470	110CE25 marcato	Bass Tuba D-Bass	32	109
471	111CS01	Bass Tuba D-Bass	32	110
472	112CS01 Es/E	Bass Tuba D-Bass	32	111
473	113DX100	Bass Tuba D-Bass	32	112
474	114DX100 Es/E	Bass Tuba D-Bass	32	113
475	115Doppelbass 1 C/Cis	Bass Tuba D-Bass	32	114
476	116Doppelbass 2 C/Cis	Bass Tuba D-Bass	32	115
477	117Doppelbass 3 C/Cis	Bass Tuba D-Bass	32	116
478	118Doppelbass 4 C/Cis	Bass Tuba D-Bass	32	117
479	120KB kurz	Bass Tuba D-Bass	32	119
480	121KB kurz C/Cis	Bass Tuba D-Bass	32	120
481	122KB kurz Es/E	Bass Tuba D-Bass	32	121
482	123KB kurz F/Fis	Bass Tuba D-Bass	32	122
483	124KB lang	Bass Tuba D-Bass	32	123
484	125KB lang C/Cis	Bass Tuba D-Bass	32	124
485	126KB lang Es/E	Bass Tuba D-Bass	32	125
486	127KB lang F/Fis	Bass Tuba D-Bass	32	126
487	128Silence	Bass Tuba D-Bass	32	127
488	80SteirischBass	Bass&Akkorde	53	79
489	81AccBass	Bass&Akkorde	53	80
490	82AccBass"	Bass&Akkorde	53	81
491	57Trompete	Bass&Tromp Sax	3	56
492	59Bartion Stac.	Bass&Tromp Sax	3	58
493	61Tenorhorn	Bass&Tromp Sax	3	60
494	67TenorSax	Bass&Tromp Sax	3	66
495	01SeppAkzent	Blech Bässe	83	0
496	03SeppVibrato	Blech Bässe	83	2
497	04SeppStaccato mezzo	Blech Bässe	83	3
498	05SeppStaccato forte	Blech Bässe	83	4
499	06EQ1Sepp Akzent	Blech Bässe	83	5
500	08EQ1Sepp Vibrato	Blech Bässe	83	7
501	09EQ1Sepp Staccato mezzo	Blech Bässe	83	8
502	10EQ1Sepp Staccato forte	Blech Bässe	83	9
503	11EQ2Sepp Akzent	Blech Bässe	83	10
504	13EQ2Sepp Vibrato	Blech Bässe	83	12
505	14EQ2Sepp Staccato mezzo	Blech Bässe	83	13
506	15EQ2Sepp Staccato forte	Blech Bässe	83	14
507	31JanezAkzent	Blech Bässe	83	30
508	33JanezVibrato	Blech Bässe	83	32
509	34JanezStaccato	Blech Bässe	83	33
510	36EQ1Janez Akzent	Blech Bässe	83	35

Nummer	Instrument	Gruppe	Bank	Programm
511	38EQ1Janez Vibrato lang	Blech Bässe	83	37
512	39EQ1Janez Staccato	Blech Bässe	83	38
513	41GlobalBass Vibrato"	Blech Bässe	83	40
514	42GlobalBass Staccato	Blech Bässe	83	41
515	43EQ1Global Bass Vibrato	Blech Bässe	83	42
516	44EQ1Global Bass Staccato	Blech Bässe	83	43
517	49SoliBaritonHornVintage	Blech Bässe	83	48
518	51JonTuba	Blech Bässe	83	50
519	52JonTubaSoft	Blech Bässe	83	51
520	56Ensemble Tuben	Blech Bässe	83	55
521	57Trumpet	Brass	0	56
522	58Trombone	Brass	0	57
523	59Bariton	Brass	0	58
524	60MutedTrp.	Brass	0	59
525	61Tenorhorn	Brass	0	60
526	62BrassSection	Brass	0	61
527	63SynthBrass 1	Brass	0	62
528	64SynthBrass 2	Brass	0	63
529	106Alphorn	Brass Alphorn	32	105
530	116Kornett	Brass Kor Pos FHor Tuba	30	115
531	117F-Horner	Brass Kor Pos FHor Tuba	30	116
532	118F-Horn	Brass Kor Pos FHor Tuba	30	117
533	119Posaune 1	Brass Kor Pos FHor Tuba	30	118
534	120Posaune 2	Brass Kor Pos FHor Tuba	30	119
535	121TrpDampfer	Brass Kor Pos FHor Tuba	30	120
536	122F-TubaStc.	Brass Kor Pos FHor Tuba	30	121
537	123F-Tuba	Brass Kor Pos FHor Tuba	30	122
538	124Tuben	Brass Kor Pos FHor Tuba	30	123
539	112Kornett	Brass Kornett	30	111
540	125Tenorhorn 1	Brass Tenorhorn	31	124
541	126Tenorhorn 2	Brass Tenorhorn	31	125
542	127Tenorhorner	Brass Tenorhorn	31	126
543	128Silence	Brass Tenorhorn	31	127
544	70TrompeteVib1	Brass Tr Flug Horner Pos	26	69
545	71TrompeteVib2	Brass Tr Flug Horner Pos	26	70
546	72TrompetenEns	Brass Tr Flug Horner Pos	26	71
547	73Flugelhorn	Brass Tr Flug Horner Pos	26	72
548	74Tenorhorn	Brass Tr Flug Horner Pos	26	73
549	75Tenorhorner	Brass Tr Flug Horner Pos	26	74
550	76Posaune	Brass Tr Flug Horner Pos	26	75
551	97TrumpetMute	Brass Tr-Basso Obo Picco	24	96
552	98Englishhorn	Brass Tr-Basso Obo Picco	24	97
553	99Cortales	Brass Tr-Basso Obo Picco	24	98
554	100Bassoon	Brass Tr-Basso Obo Picco	24	99
555	101Oboe	Brass Tr-Basso Obo Picco	24	100
556	102Horn	Brass Tr-Basso Obo Picco	24	101
557	103Piccolo	Brass Tr-Basso Obo Picco	24	102
558	105WhistleGS	Brass Tr-Basso Obo Picco	24	104
559	106Whistle	Brass Tr-Basso Obo Picco	24	105
560	107Okarina	Brass Tr-Basso Obo Picco	24	106
561	108Shanai	Brass Tr-Basso Obo Picco	24	107

Nummer	Instrument	Gruppe	Bank	Programm
562	109Shaku	Brass Tr-Basso Obo Picco	24	108
563	110Chiffer	Brass Tr-Basso Obo Picco	24	109
564	111Charang	Brass Tr-Basso Obo Picco	24	110
565	32ObTrp Vib	Brass Trp Flugelhorn	31	31
566	33ObTrp Vib.1	Brass Trp Flugelhorn	31	32
567	34ObTrp Vib Leg.	Brass Trp Flugelhorn	31	33
568	35ObTrp Vib.2	Brass Trp Flugelhorn	31	34
569	36ObTrp Mix	Brass Trp Flugelhorn	31	35
570	37ObTrp Vib. 1/4	Brass Trp Flugelhorn	31	36
571	38ObTrp Vib. 1/4	Brass Trp Flugelhorn	31	37
572	39OBTrp Vib up	Brass Trp Flugelhorn	31	38
573	40OBTrp Vib dw	Brass Trp Flugelhorn	31	39
574	41OBTrp stc. 1	Brass Trp Flugelhorn	31	40
575	42OBTrp stc. 1	Brass Trp Flugelhorn	31	41
576	43OBTrp stc. 2	Brass Trp Flugelhorn	31	42
577	44OBTrp stc. fall	Brass Trp Flugelhorn	31	43
578	45OBTrp stc. go up	Brass Trp Flugelhorn	31	44
579	47Flugelhorn Vib.	Brass Trp Flugelhorn	31	46
580	48Flugelhorn Vib.	Brass Trp Flugelhorn	31	47
581	81Cord8+ Vib. flute	Cordovox Vox4	74	80
582	82Cord8-4 Vib. flute	Cordovox Vox4	74	81
583	83Cord8-Vib. flute	Cordovox Vox4	74	82
584	84Cord84+4	Cordovox Vox4	74	83
585	85CordClar. + Vib	Cordovox Vox4	74	84
586	92Hawaii	Cordovox Vox4	74	91
587	93Hawaii Variation	Cordovox Vox4	74	92
588	106E-Bass1	E-Bass	52	105
589	110E-Bass2	E-Bass	52	109
590	115E-BassLK2	E-Bass	52	114
591	105Zither	Ethnic	0	104
592	106Banjo	Ethnic	0	105
593	107Shamisen	Ethnic	0	106
594	108Koto	Ethnic	0	107
595	109Kalimba	Ethnic	0	108
596	110Bag pipe	Ethnic	0	109
597	111Fiddle	Ethnic	0	110
598	112Shanai	Ethnic	0	111
599	107Maultrommel	Ethnic	30	106
600	95Hackbrett26	Ethnic Hackb Zither Harfe	26	94
601	97Zither26	Ethnic Hackb Zither Harfe	26	96
602	98Harfe26	Ethnic Hackb Zither Harfe	26	97
603	125Jodler	Ethnic Jodler	30	124
604	126AlpSchellen1	Ethnic Jodler	30	125
605	127AlpSchellen2	Ethnic Jodler	30	126
606	128Silence	Ethnic Jodler	30	127
607	112Alpenschellen	Ethnic Mandolin Alpschellen	26	111
608	113M-Tremolo	Ethnic Mandolin Alpschellen	26	112
609	86ZitherStc.	Ethnic Zither Hackb	30	85
610	88ZitherStc.	Ethnic Zither Hackb	30	87
611	90Zither	Ethnic Zither Hackb	30	89
612	91Zither	Ethnic Zither Hackb	30	90

Nummer	Instrument	Gruppe	Bank	Programm
613	92Zither	Ethnic Zither Hackb	30	91
614	93Zither	Ethnic Zither Hackb	30	92
615	94Hackbrett	Ethnic Zither Hackb	30	93
616	95Hackbrett	Ethnic Zither Hackb	30	94
617	96Hackbrett	Ethnic Zither Hackb	30	95
618	97Hackbrett	Ethnic Zither Hackb	30	96
619	98HackbrHolz	Ethnic Zither Hackb	30	97
620	99HackbrFilz	Ethnic Zither Hackb	30	98
621	100Harfe	Ethnic Zither Hackb	30	99
622	58Flugelhorn	Flugelhorn,Trombone	98	57
623	59Trombone Damper	Flugelhorn,Trombone	98	58
624	73Piccolo	Flute	0	72
625	74Flute	Flute	0	73
626	75Recorder	Flute	0	74
627	76PanFlute	Flute	0	75
628	77Blown Bottle	Flute	0	76
629	78Shakuhachi	Flute	0	77
630	79Whistle	Flute	0	78
631	80Ocarina	Flute	0	79
632	108Okarina	Flute	30	107
633	109Picollo	Flute	30	108
634	110Flote	Flute	30	109
635	43High Whistle	Flute	71	42
636	44High Whistle grace	Flute	71	43
637	45High Whistle slide up	Flute	71	44
638	46High Whistle grace notes	Flute	71	45
639	126FX Plattler	Fx Plattler Freddy Pfister	23	125
640	127Freddy Pfister	Fx Plattler Freddy Pfister	23	126
641	128Silence	Fx Plattler Freddy Pfister	23	127
642	121GuitarNoise	FX Sound	0	120
643	122BreathNoise	FX Sound	0	121
644	123Seashore	FX Sound	0	122
645	124Bird	FX Sound	0	123
646	125Telephone	FX Sound	0	124
647	126Helicopter	FX Sound	0	125
648	127Applaus	FX Sound	0	126
649	128empty	FX Sound	0	127
650	01Gitarre1"	Gitarre	52	0
651	03Gitarre2	Gitarre	52	2
652	05Gitarre1kurz	Gitarre	52	4
653	06Gitarre2kurz	Gitarre	52	5
654	09Gitarre3"	Gitarre	52	8
655	11Gitarre4	Gitarre	52	10
656	13Gitarre3kurz	Gitarre	52	12
657	14Gitarre4kurz	Gitarre	52	13
658	27GitMic&Amp	Gitarren,Steirisch,GBariton	98	26
659	28TirolerEcho	Gitarren,Steirisch,GBariton	98	27
660	29GitRenato	Gitarren,Steirisch,GBariton	98	28
661	30Steirische 8	Gitarren,Steirisch,GBariton	98	29
662	31JanezV	Gitarren,Steirisch,GBariton	98	30
663	32JanezL	Gitarren,Steirisch,GBariton	98	31

Nummer	Instrument	Gruppe	Bank	Programm
664	33JanezStaccato	Gitarren,Steirisch,GBariton	98	32
665	34Tenorsax	Gitarren,Steirisch,GBariton	98	33
666	35FullStrings	Gitarren,Steirisch,GBariton	98	34
667	36FullStrings2	Gitarren,Steirisch,GBariton	98	35
668	37Panflute	Gitarren,Steirisch,GBariton	98	36
669	38Flute	Gitarren,Steirisch,GBariton	98	37
670	39Renato kurz ohne	Gitarren,Steirisch,GBariton	98	38
671	40Renato lang ohne	Gitarren,Steirisch,GBariton	98	39
672	41Mundharm	Gitarren,Steirisch,GBariton	98	40
673	42SoloPosaune	Gitarren,Steirisch,GBariton	98	41
674	43Trompete	Gitarren,Steirisch,GBariton	98	42
675	44Trompete-s	Gitarren,Steirisch,GBariton	98	43
676	45Trompete h	Gitarren,Steirisch,GBariton	98	44
677	46Trompete sfz	Gitarren,Steirisch,GBariton	98	45
678	47Trompete lega	Gitarren,Steirisch,GBariton	98	46
679	48Sax 2layer	Gitarren,Steirisch,GBariton	98	47
680	49Sax piano	Gitarren,Steirisch,GBariton	98	48
681	50Noise only	Gitarren,Steirisch,GBariton	98	49
682	51Hugo Clarinet	Gitarren,Steirisch,GBariton	98	50
683	25NylonGuitar	Guitar	0	24
684	26SteelGuitar	Guitar	0	25
685	27JazzGuitar	Guitar	0	26
686	28CleanGuitar	Guitar	0	27
687	29MuteGuitar	Guitar	0	28
688	30OverdriveGit	Guitar	0	29
689	31DistortionGit	Guitar	0	30
690	32GuitarHarmonic	Guitar	0	31
691	26GuitarSteel	Guitar	3	25
692	27JazzGuitar	Guitar	3	26
693	30OverdriveGit.	Guitar	3	29
694	31DistGuitar	Guitar	3	30
695	32GuitarSteel	Guitar	3	31
696	31DistGuitar	Guitar	4	30
697	59GuitarAcousticSteel soft	Guitar	24	58
698	60GuitarJazz	Guitar	24	59
699	61GuitarClean	Guitar	24	60
700	62GuitarMute	Guitar	24	61
701	101Konzertgitarre	Guitar	26	100
702	102RhythmusGit26	Guitar	26	101
703	103PickGit26	Guitar	26	102
704	104JazzGit26	Guitar	26	103
705	105JazzGit26	Guitar	26	104
706	106HawaiGit.	Guitar	26	105
707	104Konzertgit.	Guitar	30	103
708	105Konzertgit.	Guitar	30	104
709	101Castello kurz	Guitar	98	100
710	102Castello medium	Guitar	98	101
711	103Castello lang	Guitar	98	102
712	65GuitarDistortion	Guitar Distortion	24	64
713	39JazzGitJazz AmpMikroPolka	Guitar EdiKöhldorferAmpMikro	84	38
714	41JazzGitJazz AmpMikroWalzer	Guitar EdiKöhldorferAmpMikro	84	40

Nummer	Instrument	Gruppe	Bank	Programm
715	42JazzGitJazz AmpMikroLang	Guitar EdiKöhldorferAmpMikro	84	41
716	01NylGitPolka	Guitar Nylon	84	0
717	03NylGitWalzer	Guitar Nylon	84	2
718	04NylGitLang	Guitar Nylon	84	3
719	72GuitarOverdrive	Guitar Overdr Sax Flute	24	71
720	73SaxSopran	Guitar Overdr Sax Flute	24	72
721	74SaxBariton	Guitar Overdr Sax Flute	24	73
722	75SaxSopranSoft	Guitar Overdr Sax Flute	24	74
723	77Panflute	Guitar Overdr Sax Flute	24	76
724	78Flute	Guitar Overdr Sax Flute	24	77
725	79SynthCalliope	Guitar Overdr Sax Flute	24	78
726	80SynthBottle	Guitar Overdr Sax Flute	24	79
727	81BowedGlass	Guitar Overdr Sax Flute	24	80
728	16VerlicGitMikroPolka	Guitar Renato Verlic	84	15
729	18VerlicGitMikroWalzer"	Guitar Renato Verlic	84	17
730	19VerlicGitMikroLang	Guitar Renato Verlic	84	18
731	33 Rhythm Git 6	Guitar Rhythm	24	32
732	34 Rhythm Git 7	Guitar Rhythm	24	33
733	35 Rhythm Git 8	Guitar Rhythm	24	34
734	36 Rhythm Git 9	Guitar Rhythm	24	35
735	01 Castello 1	Guitar Rhytm	33	0
736	02 Castello 1 kurz	Guitar Rhytm	33	1
737	03 Castello 2	Guitar Rhytm	33	2
738	04 Castello 2 kurz	Guitar Rhytm	33	3
739	05 Castello 3	Guitar Rhytm	33	4
740	06 Castello 3 kurz	Guitar Rhytm	33	5
741	07 Castello_AZ10 1	Guitar Rhytm	33	6
742	08 Castello_AZ10 1 kurz	Guitar Rhytm	33	7
743	09 Castello_AZ10 2	Guitar Rhytm	33	8
744	10 Castello_AZ10 2 kurz	Guitar Rhytm	33	9
745	11 Castello_AZ10 3	Guitar Rhytm	33	10
746	12 Castello_AZ10 3 kurz	Guitar Rhytm	33	11
747	13 Akkordgit. 1	Guitar Rhytm	33	12
748	14 Akkordgit. 1 kurz	Guitar Rhytm	33	13
749	15 Akkordgit. 2	Guitar Rhytm	33	14
750	16 Akkordgit. 2 kurz	Guitar Rhytm	33	15
751	17 Castello lang 1	Guitar Rhytm	33	16
752	18 Castello lang 2	Guitar Rhytm	33	17
753	19 Castello lang	Guitar Rhytm	33	18
754	21Rhythmusgit. 1	Guitar Rhytm	33	20
755	22Rhythmusgit. 2	Guitar Rhytm	33	21
756	23Rhythmusgit. 3	Guitar Rhytm	33	22
757	24Rhythmusgit.FX	Guitar Rhytm	33	23
758	27 Rhythmusgit.Akk.	Guitar Rhytm	33	26
759	29 R.git.Akk.lang1	Guitar Rhytm	33	28
760	30 R.git.Akk.lang2	Guitar Rhytm	33	29
761	31 R.git.2	Guitar Rhytm	33	30
762	32 Rhy.git.3	Guitar Rhytm	33	31
763	33 Rhy.git.3 lang	Guitar Rhytm	33	32
764	71Hackbrett 4	Guitar Saiten Instr.& Div.	81	70
765	72Hackbrett 4+	Guitar Saiten Instr.& Div.	81	71

Nummer	Instrument	Gruppe	Bank	Programm
766	73Hackbr.IAK Duett Low	Guitar Saiten Instr.& Div.	81	72
767	74Hackbr.IAK Duett High	Guitar Saiten Instr.& Div.	81	73
768	77Zither	Guitar Saiten Instr.& Div.	81	76
769	81Nylon Zupfgitarre	Guitar Saiten Instr.& Div.	81	80
770	82Nylon Zupfgitarre	Guitar Saiten Instr.& Div.	81	81
771	83Rhythm Git. Rhythmus	Guitar Saiten Instr.& Div.	81	82
772	84Rhythm Git. Rhythmus	Guitar Saiten Instr.& Div.	81	83
773	85Jazz Gitarre Castello	Guitar Saiten Instr.& Div.	81	84
774	87Jazz Gitarre Micro	Guitar Saiten Instr.& Div.	81	86
775	88Jazz Gitarre Amp	Guitar Saiten Instr.& Div.	81	87
776	89Jazz Gitarre Micro	Guitar Saiten Instr.& Div.	81	88
777	90Jazz Gitarre Amp	Guitar Saiten Instr.& Div.	81	89
778	91Harfe	Guitar Saiten Instr.& Div.	81	90
779	92Harfe mit Ausklang	Guitar Saiten Instr.& Div.	81	91
780	93Harfe Arpeggio	Guitar Saiten Instr.& Div.	81	92
781	111Geige Vibrato	Guitar Saiten Instr.& Div.	81	110
782	112Geige Arco	Guitar Saiten Instr.& Div.	81	111
783	113Geige Slide	Guitar Saiten Instr.& Div.	81	112
784	127Maultrommel	Guitar Saiten Instr.& Div.	81	126
785	101ArpNylonGitarreSlowArpeggio	GuitarArpeggio	84	100
786	102ArpJazzGitarreSlowArpeggio	GuitarArpeggio	84	101
787	54JazzBass-Ran	Jazz Bass	98	53
788	55JazzBass	Jazz Bass	98	54
789	56JazzBass	Jazz Bass	98	55
790	57JazzBass	Jazz Bass	98	56
791	111Klarinetten	Klarinette	30	110
792	01OB Klar. 1	Klarinette	31	0
793	02OB Klar. 2	Klarinette	31	1
794	03OB Klar. soft	Klarinette	31	2
795	04OB Klar. 3	Klarinette	31	3
796	05OB Klar. Leg	Klarinette	31	4
797	06OB Klar. 1	Klarinette	31	5
798	07OB Klar. stc.	Klarinette	31	6
799	42Klarinette1	Klarinette	53	41
800	44Klarinette2	Klarinette	53	43
801	46Klarinette3	Klarinette	53	45
802	48Klarinette4	Klarinette	53	47
803	57Klarinette	Klarinette Sax	26	56
804	58KlarVib1	Klarinette Sax	26	57
805	59KlarVib2	Klarinette Sax	26	58
806	60KlarStc.	Klarinette Sax	26	59
807	61SopranSax	Klarinette Sax	26	60
808	63AltSaxVib1	Klarinette Sax	26	62
809	64AltSaxVib2	Klarinette Sax	26	63
810	65AltSax	Klarinette Sax	26	64
811	66TenorSaxVib1	Klarinette Sax	26	65
812	67TenorSaxVib2	Klarinette Sax	26	66
813	68TenorSax1	Klarinette Sax	26	67
814	69TenorSax2	Klarinette Sax	26	68
815	52Martin auf	Klarinette,Trompet,Aufsteigent	98	51
816	53Tromp Ivan auf	Klarinette,Trompet,Aufsteigent	98	52

Nummer	Instrument	Gruppe	Bank	Programm
817	81KontraBass1Mic	Kontrabass	52	80
818	89KontraBass2	Kontrabass	52	88
819	97KontraBass3	Kontrabass	52	96
820	25Mandoline.	Mandoline	3	24
821	01Mandolins	Mandoline	75	0
822	02Mandolins+	Mandoline	75	1
823	03MandoPick	Mandoline	75	2
824	55Mundharmonika	Mundharmonika	26	54
825	56Mundhar Vib.	Mundharmonika	26	55
826	60Oergeli	Oergeli,Streichbass,Guitar	98	59
827	61SwissGestrichen	Oergeli,Streichbass,Guitar	98	60
828	17DrawbarOrgan	Organ	0	16
829	18PercOrgan	Organ	0	17
830	19RockOrgan	Organ	0	18
831	20ChurchOrgan	Organ	0	19
832	21ReedOrgan	Organ	0	20
833	17DrawbarOrgan	Organ	3	16
834	18DigiOrgan	Organ	3	17
835	19RockOrgan	Organ	3	18
836	20ChurchOrgan	Organ	3	19
837	17HamOrgan	Organ	4	16
838	18DigiOrgan	Organ	4	17
839	19JazzOrgan	Organ	4	18
840	20ChurchOrgan	Organ	4	19
841	17Organ	Organ	5	16
842	18PercRotary	Organ	5	17
843	19JazzOrgan	Organ	5	18
844	31DistGuitar	Organ	5	30
845	17DigiOrgan	Organ	6	16
846	18PercOrgan	Organ	6	17
847	19RockOrgan	Organ	6	18
848	18Digi Organ	Organ	7	17
849	19Rock Organ 2	Organ	7	18
850	01Jimmy Smith	Organ	99	0
851	02Joey DeFrancesco	Organ	99	1
852	03Charles Earland	Organ	99	2
853	04Brian Auger	Organ	99	3
854	05Garner-Set	Organ	99	4
855	06Piano Set8	Organ	99	5
856	07Walter Wanderley	Organ	99	6
857	08Whistle	Organ	99	7
858	09Gospel Set	Organ	99	8
859	10Blues Set	Organ	99	9
860	11EasyListening	Organ	99	10
861	12Jimmy Smith	Organ	99	11
862	13Jimmy Smith	Organ	99	12
863	14Joey Defrancesco	Organ	99	13
864	15Ballad2	Organ	99	14
865	16Jesse Crawford	Organ	99	15
866	17Joey Defrancesco	Organ	99	16
867	18BookerT.Jones	Organ	99	17

Nummer	Instrument	Gruppe	Bank	Programm
868	19Green Onions	Organ	99	18
869	20MatthewFisher	Organ	99	19
870	21JimmyMcGriffGospel	Organ	99	20
871	22Chords	Organ	99	21
872	23Chords	Organ	99	22
873	24Walter Wanderley	Organ	99	23
874	25Walter Wanderley	Organ	99	24
875	26Lenny Dee	Organ	99	25
876	27Lenny Dee	Organ	99	26
877	28Lenny Dee	Organ	99	27
878	29Ethel Smith	Organ	99	28
879	30Ken Griffin	Organ	99	29
880	31Jon Lord	Organ	99	30
881	32JimmySmith	Organ	99	31
882	33Jimm Smith	Organ	99	32
883	34Exclusive	Organ	99	33
884	35Exclusive	Organ	99	34
885	36Standard	Organ	99	35
886	37Standard	Organ	99	36
887	38Standard	Organ	99	37
888	39Standard	Organ	99	38
889	40Standard	Organ	99	39
890	21FLSpezial 1 slow	Organ German Entertainer	74	20
891	22FLSpezial 1 fast	Organ German Entertainer	74	21
892	33RDVoll 3 slow	Organ German Entertainer	74	32
893	34RDVoll 3 fast	Organ German Entertainer	74	33
894	35KW Musical	Organ German Entertainer	74	34
895	36UK Mersi	Organ German Entertainer	74	35
896	37Organ1 OAS	Organ German Entertainer	74	36
897	38Organ2 OAS	Organ German Entertainer	74	37
898	39L100Vintage	Organ German Entertainer	74	38
899	40L100 Vintage	Organ German Entertainer	74	39
900	47Organ DB Full fast	Organ German Entertainer	74	46
901	48Organ DB Full slow	Organ German Entertainer	74	47
902	53Organ W2 Perc 1	Organ German Entertainer	74	52
903	54Organ W2 Perc 3	Organ German Entertainer	74	53
904	55Organ ZR Sine fast	Organ German Entertainer	74	54
905	56Organ ZR Sine slow	Organ German Entertainer	74	55
906	57Organ ZR Perc fast	Organ German Entertainer	74	56
907	58Organ ZR Perc slow	Organ German Entertainer	74	57
908	01776555678 slow	Organ Ham B3	74	0
909	02776555678 fast	Organ Ham B3	74	1
910	03800000568 slow	Organ Ham B3	74	2
911	04800000568 fast	Organ Ham B3	74	3
912	05008530000 slow	Organ Ham B3	74	4
913	06008530000 fast	Organ Ham B3	74	5
914	07800000000 slow	Organ Ham B3	74	6
915	08800000000 fast	Organ Ham B3	74	7
916	09807800000 slow	Organ Ham B3	74	8
917	10807800000 fast	Organ Ham B3	74	9
918	11804708000 slow	Organ Ham B3	74	10

Nummer	Instrument	Gruppe	Bank	Programm
919	12804708000 fast	Organ Ham B3	74	11
920	13800008000 slow	Organ Ham B3	74	12
921	14800008000 fast	Organ Ham B3	74	13
922	19880000000 Perc. sl	Organ Ham B3	74	18
923	20888888888 full	Organ Ham B3	74	19
924	41Tower Mighty	Organ Theater	74	40
925	42Tower Piston 2	Organ Theater	74	41
926	44Bass Pedals Small	Organ Theater	74	43
927	45Bass Pedals Full	Organ Theater	74	44
928	46Bass Dixon Pedals	Organ Theater	74	45
929	89NewAge	Pads	0	88
930	90Warm Pad	Pads	0	89
931	91Polysynth	Pads	0	90
932	92Space	Pads	0	91
933	93Bowed	Pads	0	92
934	94Metallic	Pads	0	93
935	95Halo	Pads	0	94
936	96Sweep	Pads	0	95
937	97Rain	Pads	0	96
938	98Soundtrack	Pads	0	97
939	99Crystal	Pads	0	98
940	100Atmosphere	Pads	0	99
941	101Brightness	Pads	0	100
942	102Goblins	Pads	0	101
943	103Echoes	Pads	0	102
944	104StarThem	Pads	0	103
945	94Digitalic	Padsounds	3	93
946	97SlightBells	Padsounds	3	96
947	99HyperCrystal	Padsounds	3	98
948	103Echo Pan	Padsounds	3	102
949	113TinkleBell	Percussion	0	112
950	114Agogo	Percussion	0	113
951	115SteelDrums	Percussion	0	114
952	116Woodblock	Percussion	0	115
953	117TaikoDrum	Percussion	0	116
954	118MelodicTom	Percussion	0	117
955	119SynthDrum	Percussion	0	118
956	120ReverseCymbal	Percussion	0	119
957	01GrandPiano	Piano	4	0
958	85E-PianoFM 2	Piano Bass Voice	24	84
959	86DulcimerAustria	Piano Bass Voice	24	85
960	87Clavinet	Piano Bass Voice	24	86
961	88Harpsichord	Piano Bass Voice	24	87
962	89Timpani	Piano Bass Voice	24	88
963	90Celesta	Piano Bass Voice	24	89
964	91MusicBox	Piano Bass Voice	24	90
965	92TubBell	Piano Bass Voice	24	91
966	93Harmonium	Piano Bass Voice	24	92
967	94SynthBass1	Piano Bass Voice	24	93
968	95SynthBass2	Piano Bass Voice	24	94
969	96VoiceDoo	Piano Bass Voice	24	95

Nummer	Instrument	Gruppe	Bank	Programm
970	51E-PianoFM	Piano Grand E-Piano	24	50
971	52E-PianoDyno	Piano Grand E-Piano	24	51
972	53E-PianoBell	Piano Grand E-Piano	24	52
973	54Grand Piano-no velocity	Piano Grand E-Piano	24	53
974	55Grand Piano	Piano Grand E-Piano	24	54
975	56GrandPianoBright	Piano Grand E-Piano	24	55
976	57HonkyTonk	Piano Grand E-Piano	24	56
977	58ElecGrand	Piano Grand E-Piano	24	57
978	01GrandPiano	Piano&EPiano	0	0
979	02BrightGrand	Piano&EPiano	0	1
980	03Electric Grand	Piano&EPiano	0	2
981	04HonkyTonk	Piano&EPiano	0	3
982	05E-PianoTine	Piano&EPiano	0	4
983	06E-PianoFM	Piano&EPiano	0	5
984	07Harpichord	Piano&EPiano	0	6
985	08Clavinet	Piano&EPiano	0	7
986	01Grand Piano	Piano&EPiano	3	0
987	05E-Piano	Piano&EPiano	3	4
988	10Irish Pipe	Pipe Irish	75	9
989	11Irish Pipe AV	Pipe Irish	75	10
990	12Irish Pipe AV Slide116	Pipe Irish	75	11
991	13Irish Pipe Drone	Pipe Irish	75	12
992	14Highland Pipe	Pipe Scottish Highl	75	13
993	15Highl Pipe AV	Pipe Scottish Highl	75	14
994	16Highl Pipe Drone	Pipe Scottish Highl	75	15
995	68SaxSection	Sax	4	67
996	37AltoSax	Sax	24	36
997	38AltoSaxSoft	Sax	24	37
998	39AltoSaxHard	Sax	24	38
999	40AltoSaxNoisy	Sax	24	39
1000	41TenorSax	Sax	24	40
1001	42TenorSaxSoft	Sax	24	41
1002	43TenorSaxHard	Sax	24	42
1003	44TenorSaxNoisy	Sax	24	43
1004	45TenorSaxMedium	Sax	24	44
1005	46TSaxSection	Sax	24	45
1006	47TSaxSecSoft	Sax	24	46
1007	113Sopran Sax	Sax	30	112
1008	114AltoSax	Sax	30	113
1009	115TenorSax	Sax	30	114
1010	13TrumpetSection	Sax Choir Klarinett Flute	24	12
1011	14TenorSaxFunky	Sax Choir Klarinett Flute	24	13
1012	15TenorSaxGrowl	Sax Choir Klarinett Flute	24	14
1013	16TenorSaxSP116	Sax Choir Klarinett Flute	24	15
1014	17AltoSax	Sax Choir Klarinett Flute	24	16
1015	18AltoSaxsoft	Sax Choir Klarinett Flute	24	17
1016	19ChoirOoh	Sax Choir Klarinett Flute	24	18
1017	20ChoirOhh	Sax Choir Klarinett Flute	24	19
1018	21KlarinetCarlo	Sax Choir Klarinett Flute	24	20
1019	22KlarinetCarloEQ	Sax Choir Klarinett Flute	24	21
1020	23SopranSaxCarlo	Sax Choir Klarinett Flute	24	22

Nummer	Instrument	Gruppe	Bank	Programm
1021	24Flute	Sax Choir Klarinett Flute	24	23
1022	25Flute Q	Sax Choir Klarinett Flute	24	24
1023	01Trompete Ivan	Solo Blech	81	0
1024	02Trompete Ivan	Solo Blech	81	1
1025	03Trompete Ivan 1/4tel	Solo Blech	81	2
1026	04Trompete Ivan 1/4tel	Solo Blech	81	3
1027	05Trompete Ivan Staccato	Solo Blech	81	4
1028	07Trompete soft	Solo Blech	81	6
1029	08Trompete hard	Solo Blech	81	7
1030	10Trompete softup	Solo Blech	81	9
1031	11Trompeten EnsembleLP	Solo Blech	81	10
1032	12Trompeten EnsembleHP	Solo Blech	81	11
1033	13Trompeten EnsembleNOT	Solo Blech	81	12
1034	15Flügelhorn Ivan	Solo Blech	81	14
1035	19Trompete Dämpfer	Solo Blech	81	18
1036	21Sepp Akzent fast	Solo Blech	81	20
1037	22Sepp Akzent	Solo Blech	81	21
1038	23Sepp Vibrato	Solo Blech	81	22
1039	24Sepp Staccato mezzo	Solo Blech	81	23
1040	25Sepp Staccato forte	Solo Blech	81	24
1041	41Janez Akzent	Solo Blech	81	40
1042	43Janez Vibrato	Solo Blech	81	42
1043	44Janez Staccato mezzo	Solo Blech	81	43
1044	51Global Bass Vibrato	Solo Blech	81	50
1045	52Global Bass Staccato	Solo Blech	81	51
1046	55Tenorhorn Vibrato	Solo Blech	81	54
1047	59French horn	Solo Blech	81	58
1048	61Martin Vibrato	Solo Holz Klarinette	81	60
1049	62Martin soft	Solo Holz Klarinette	81	61
1050	63Martin Slide	Solo Holz Klarinette	81	62
1051	66VitoVibrato	Solo Holz Klarinette	81	65
1052	67VitoVibrato	Solo Holz Klarinette	81	66
1053	68VitoStaccato	Solo Holz Klarinette	81	67
1054	69VitoStaccato	Solo Holz Klarinette	81	68
1055	70Ensemble Clarinets	Solo Holz Klarinette	81	69
1056	06Pedal Steel Vib	Steel Pedal	75	5
1057	07PSteel Vib Slide	Steel Pedal	75	6
1058	08PSteel flat	Steel Pedal	75	7
1059	09PSteel fade	Steel Pedal	75	8
1060	67Modell1"	Steirisch	53	66
1061	68Modell2	Steirisch	53	67
1062	69Modell3	Steirisch	53	68
1063	70Modell4	Steirisch	53	69
1064	45Strings	Strings	4	44
1065	51SynthStr	Strings	4	50
1066	49StringEns	Strings	5	48
1067	50StringEns	Strings	5	49
1068	51SynthStr	Strings	5	50
1069	41Violin	Strings Choir	0	40
1070	42Viola	Strings Choir	0	41
1071	43Cello	Strings Choir	0	42

Nummer	Instrument	Gruppe	Bank	Programm
1072	44Contrabass	Strings Choir	0	43
1073	45TremoloStr.	Strings Choir	0	44
1074	46Pizzicato	Strings Choir	0	45
1075	47Harp	Strings Choir	0	46
1076	48Timpani	Strings Choir	0	47
1077	49StringEnsemble	Strings Choir	0	48
1078	50StringSlow	Strings Choir	0	49
1079	51SynthStrings	Strings Choir	0	50
1080	52SynthStrings	Strings Choir	0	51
1081	53Choir ahs	Strings Choir	0	52
1082	54VoiceOohs	Strings Choir	0	53
1083	55SynthVoice	Strings Choir	0	54
1084	56OrchestraHit	Strings Choir	0	55
1085	99Fiddle1	Strings Fiddle	26	98
1086	100Fiddle2	Strings Fiddle	26	99
1087	84NylonGuitarSoft	Strings Fidl Vibr Banjo	23	83
1088	85JazzVibraphon	Strings Fidl Vibr Banjo	23	84
1089	86SteelGuitar	Strings Fidl Vibr Banjo	23	85
1090	87FiddleCeltic	Strings Fidl Vibr Banjo	23	86
1091	88Woodblock	Strings Fidl Vibr Banjo	23	87
1092	89Taiko	Strings Fidl Vibr Banjo	23	88
1093	90FullStringsForte	Strings Fidl Vibr Banjo	23	89
1094	92FullStringsPiano	Strings Fidl Vibr Banjo	23	91
1095	93BanjoSlideUp	Strings Fidl Vibr Banjo	23	92
1096	98GuitarSpanishSlideUp	Strings Fidl Vibr Banjo	23	97
1097	99AcousticSteel2	Strings Fidl Vibr Banjo	23	98
1098	100AcousticSteel2soft	Strings Fidl Vibr Banjo	23	99
1099	1FullStrings 2	Strings Full	24	0
1100	2FullStrings 3	Strings Full	24	1
1101	3FullStrings 4	Strings Full	24	2
1102	4Strings Detache	Strings Full	24	3
1103	5FullStrings 5	Strings Full	24	4
1104	6FullStrings 6	Strings Full	24	5
1105	7FullStrings 7	Strings Full	24	6
1106	8FullStrings 8	Strings Full	24	7
1107	101Geige	Strings Geige	30	100
1108	102Geige	Strings Geige	30	101
1109	103Geige	Strings Geige	30	102
1110	66SoloViolinClassic	Strings Solo Violin Kontra	24	65
1111	67SoloViolaClassic	Strings Solo Violin Kontra	24	66
1112	68SoloCelloClassic	Strings Solo Violin Kontra	24	67
1113	69SoloContrabassClassic	Strings Solo Violin Kontra	24	68
1114	70FullStirngsremolo	Strings Solo Violin Kontra	24	69
1115	71FullStringsPizzi	Strings Solo Violin Kontra	24	70
1116	49StringEnsemble	Strings&Choir	3	48
1117	51SynthStrings 1	Strings&Choir	3	50
1118	54Voice	Strings&Choir	3	53
1119	55Vox	Strings&Choir	3	54
1120	81SquareLead	Synth	0	80
1121	82SawLead	Synth	0	81
1122	83Calliope	Synth	0	82

Nummer	Instrument	Gruppe	Bank	Programm
1123	84Chiff	Synth	0	83
1124	85Charang	Synth	0	84
1125	86SoloVox	Synth	0	85
1126	87Fifths	Synth	0	86
1127	88BassLead	Synth	0	87
1128	94Digi	Synth	4	93
1129	26Fantasia	Synth	24	25
1130	27Brightness	Synth	24	26
1131	28SynthBrass3	Synth	24	27
1132	29StarThem2	Synth	24	28
1133	30SawLead1	Synth	24	29
1134	31SawLead2	Synth	24	30
1135	32SynthBrass4	Synth	24	31
1136	82SynthSquareLead	Synth	24	81
1137	83SynthSpace	Synth	24	82
1138	84SoftPad	Synth	24	83
1139	112BassLead	Synth	24	111
1140	113Synth5th	Synth	24	112
1141	114MetalPad	Synth	24	113
1142	115PolyBrassSynth	Synth	24	114
1143	116SweepJuno	Synth	24	115
1144	117HaloPad	Synth	24	116
1145	118IceRain	Synth	24	117
1146	119Goblin	Synth	24	118
1147	120Soundtrack5	Synth	24	119
1148	121Polysynth	Synth	24	120
1149	122Synthup	Synth	24	121
1150	123FadeSynth	Synth	24	122
1151	124Crystal	Synth	24	123
1152	125Atmos	Synth	24	124
1153	126Kalima	Synth	24	125
1154	127Agogo	Synth	24	126
1155	128Silence	Synth	24	127
1156	105Glocken hit	Tower Reiteration	74	104
1157	106Glocken hit short	Tower Reiteration	74	105
1158	107Glocken Reiter	Tower Reiteration	74	106
1159	108Xylophon hit	Tower Reiteration	74	107
1160	109Xylophon Reiter	Tower Reiteration	74	108
1161	110Xylophon and hit	Tower Reiteration	74	109
1162	126Glocken no velocity	Tower Reiteration	74	125
1163	127Xylophon no velocity	Tower Reiteration	74	126
1164	36Flügelhorn	Trompete	53	35
1165	38Trompete1	Trompete	53	37
1166	40Trompete2	Trompete	53	39
1167	18TrpSoft	Trompete,Klarinet,Bariton	98	17
1168	19TrpHard	Trompete,Klarinet,Bariton	98	18
1169	20TrpIvan	Trompete,Klarinet,Bariton	98	19
1170	21ClVito	Trompete,Klarinet,Bariton	98	20
1171	22ClMartin	Trompete,Klarinet,Bariton	98	21
1172	23AlenBariton	Trompete,Klarinet,Bariton	98	22
1173	24SeppBaritonStaccato	Trompete,Klarinet,Bariton	98	23

Nummer	Instrument	Gruppe	Bank	Programm
1174	25SeppBaritonVib	Trompete,Klarinet,Bariton	98	24
1175	26EB Moto	Trompete,Klarinet,Bariton	98	25
1176	112TrumpetMuteAV	Trp mute Mundh Harp	23	111
1177	113E-BassSlap 1	Trp mute Mundh Harp	23	112
1178	114E-Bass lap 2	Trp mute Mundh Harp	23	113
1179	115Glockenspiel	Trp mute Mundh Harp	23	114
1180	116Harp	Trp mute Mundh Harp	23	115
1181	117Vibraphon Vibrato	Trp mute Mundh Harp	23	116
1182	09Celesta	Tuned Percussion	0	8
1183	10Glockenspiel	Tuned Percussion	0	9
1184	11Music Box	Tuned Percussion	0	10
1185	12Vibraphon	Tuned Percussion	0	11
1186	13Marimba	Tuned Percussion	0	12
1187	14Xylaphon	Tuned Percussion	0	13
1188	15Tubular Bell	Tuned Percussion	0	14
1189	16Hackbrett	Tuned Percussion	0	15
1190	1SQLead 1	Universal	23	0
1191	2Lead Analog 1	Universal	23	1
1192	3TB303Lead	Universal	23	2
1193	4SawJP8	Universal	23	3
1194	5MiniMoo1	Universal	23	4
1195	6HookLead1	Universal	23	5
1196	7HookLead CS8	Universal	23	6
1197	8HookLead 2	Universal	23	7
1198	9M-Synth Rezo	Universal	23	8
1199	10M-Synthz	Universal	23	9
1200	11BassLead 2	Universal	23	10
1201	12FMPlunk	Universal	23	11
1202	13FMBrass	Universal	23	12
1203	14LaBoum+	Universal	23	13
1204	15LaBoum	Universal	23	14
1205	16Pad200	Universal	23	15
1206	17Pad300	Universal	23	16
1207	18Pad300mono	Universal	23	17
1208	19Pad302HPF	Universal	23	18
1209	20Polysynth	Universal	23	19
1210	21PadJuno	Universal	23	20
1211	22DXBrass	Universal	23	21
1212	23DXPrassHPF	Universal	23	22
1213	25FXBello	Universal	23	24
1214	26AtmoBell	Universal	23	25
1215	27Atmoness	Universal	23	26
1216	28PWSstereo	Universal	23	27
1217	29PWSmono	Universal	23	28
1218	30SYX1Bell	Universal	23	29
1219	31SYX2Bell	Universal	23	30
1220	35ArpegyFM	Universal	23	34
1221	36Arpegyko	Universal	23	35
1222	38ArpegSY	Universal	23	37
1223	39ArpegTEK	Universal	23	38
1224	40Overhome	Universal	23	39

Nummer	Instrument	Gruppe	Bank	Programm
1225	41BellaveStereo	Universal	23	40
1226	42Bellavemono	Universal	23	41
1227	43PXBells	Universal	23	42
1228	44FMBells	Universal	23	43
1229	45AnalogBell	Universal	23	44
1230	46Modular55	Universal	23	45
1231	47Brightmono	Universal	23	46
1232	51Lovesynth	Universal	23	50
1233	52Bright8	Universal	23	51
1234	53BrightO	Universal	23	52
1235	54BrightF	Universal	23	53
1236	55Beauty7	Universal	23	54
1237	56BeautyF	Universal	23	55
1238	57BellHit	Universal	23	56
1239	58BellSpectra	Universal	23	57
1240	60ElectronicSteel	Universal	23	59
1241	62StrHigh	Universal	23	61
1242	63StrENV	Universal	23	62
1243	65Sopran Sax	Woodwinds Sax Horn	0	64
1244	66Alto Sax	Woodwinds Sax Horn	0	65
1245	67Tenor Sax	Woodwinds Sax Horn	0	66
1246	68Bariton Sax	Woodwinds Sax Horn	0	67
1247	69Oboe	Woodwinds Sax Horn	0	68
1248	70EnglishHorn	Woodwinds Sax Horn	0	69
1249	71Bassoon	Woodwinds Sax Horn	0	70
1250	72Klarinet	Woodwinds Sax Horn	0	71
1251	68Cloudy	Xylo Choir Sax Cor Strings	23	67
1252	69Stryngs	Xylo Choir Sax Cor Strings	23	68
1253	70Fantasymono	Xylo Choir Sax Cor Strings	23	69
1254	71Matrix12stereo	Xylo Choir Sax Cor Strings	23	70
1255	72Matrix12mono	Xylo Choir Sax Cor Strings	23	71
1256	73FullStrings2018	Xylo Choir Sax Cor Strings	23	72
1257	74Xylophon	Xylo Choir Sax Cor Strings	23	73
1258	75Xylphon+Oct	Xylo Choir Sax Cor Strings	23	74
1259	76ChoirOoh	Xylo Choir Sax Cor Strings	23	75
1260	77ChoirAAh	Xylo Choir Sax Cor Strings	23	76
1261	78CornetVib	Xylo Choir Sax Cor Strings	23	77
1262	79CornetSoft	Xylo Choir Sax Cor Strings	23	78
1263	80CornetHard	Xylo Choir Sax Cor Strings	23	79
1264	81CornetPorta	Xylo Choir Sax Cor Strings	23	80
1265	82TenorsaxBallroom	Xylo Choir Sax Cor Strings	23	81
1266	83TenorsaxJazz	Xylo Choir Sax Cor Strings	23	82
1267	01Xylophon	Yylophon,Chor,Cornet	98	0
1268	02ChorOhh	Yylophon,Chor,Cornet	98	1
1269	03ChorAhh	Yylophon,Chor,Cornet	98	2
1270	05Cornet	Yylophon,Chor,Cornet	98	4
1271	Dance Kick	Bass Drum	1	7
1272	Dance Kick	Bass Drum	1	8
1273	Dance Kick	Bass Drum	1	9
1274	Dance Kick	Bass Drum	1	10
1275	Dance Kick	Bass Drum	1	11

Nummer	Instrument	Gruppe	Bank	Programm
1276	Dance Kick	Bass Drum	1	12
1277	Bass Drum LS Ludw	Bass Drum	1	33
1278	Snare Var. LS Cravio	Bass Drum	1	34
1279	Bass Drum LS Ludw	Bass Drum	1	35
1280	Bass Drum LS Ludw	Bass Drum	1	36
1281	909 BD 1	BASSDRUM	25	21
1282	909 BD 2	BASSDRUM	25	22
1283	Bass drum	BASSDRUM	29	31
1284	Bass drum	BASSDRUM	29	32
1285	Kick Soft	BASSDRUM	0	33
1286	Bass drum	BASSDRUM	29	33
1287	Jazz Kick 3	BASSDRUM	32	33
1288	Brush Kick 2	BASSDRUM	40	33
1289	Bass drum	BASSDRUM	29	34
1290	Kick 1	BASSDRUM	0	35
1291	Hit Kick 1	BASSDRUM	4	35
1292	Power Kick 1	BASSDRUM	16	35
1293	Elec Kick 1	BASSDRUM	24	35
1294	808 Kick	BASSDRUM	25	35
1295	Bass drum	BASSDRUM	29	35
1296	Jazz Kick 1	BASSDRUM	32	35
1297	Brush Kick 1	BASSDRUM	40	35
1298	Orch. Drum 1	BASSDRUM	48	35
1299	Kick 2	BASSDRUM	0	36
1300	Hit Kick 2	BASSDRUM	4	36
1301	Power Kick 2	BASSDRUM	16	36
1302	Elec Kick 2	BASSDRUM	24	36
1303	808 Kick	BASSDRUM	25	36
1304	Orch. Drum 2	BASSDRUM	29	36
1305	Jazz Kick 2	BASSDRUM	32	36
1306	Brush Kick 2	BASSDRUM	40	36
1307	Orch. Drum 2	BASSDRUM	48	36
1308	große Tr. tief	BASSDRUM	29	74
1309	große Tr. tief	BASSDRUM	29	75
1310	große Tr. tief	BASSDRUM	29	76
1311	große Tr. tief	BASSDRUM	29	77
1312	große Tr. tief	BASSDRUM	29	78
1313	große Tr. tief	BASSDRUM	29	79
1314	Große Tr.	BASSDRUM	29	80
1315	Gr. Trm. offen	BASSDRUM	29	81
1316	Gr. Trommel 2	BASSDRUM	29	82
1317	Gr. Trm. stopp	BASSDRUM	29	83
1318	Gr. Trm. 2	BASSDRUM	29	84
1319	Gr. Trommel & Cym	BASSDRUM	29	85
1320	Gr. Trommel 3	BASSDRUM	29	86
1321	Gr. Trommel offen	BASSDRUM	29	87
1322	Bongo high [Repetition]	Bongo	1	60
1323	Bongo low [Repetition]	Bongo	1	61
1324	Conga mute [Repetition]	Bongo	1	62
1325	Conga open [Repetition]	Bongo	1	63
1326	Conga low [Repetition]	Bongo	1	64

Nummer	Instrument	Gruppe	Bank	Programm
1327	Timbale high [Repetition]	Bongo	1	65
1328	Timbale low [Repetition]	Bongo	1	66
1329	Agogo high [Repetition]	Bongo	1	67
1330	Agogo low [Repetition]	Bongo	1	68
1331	Claps Hit 1	Claps	1	109
1332	Claps Hit 2	Claps	1	110
1333	Claps Hit 3	Claps	1	111
1334	Claps Hit 4	Claps	1	112
1335	Stomp 1	Claps	1	113
1336	Stomp 2	Claps	1	114
1337	Stomp 3	Claps	1	115
1338	Reverse Stomp	Cymb	1	116
1339	Reverse Snare	Cymb	1	117
1340	Reverse Clap	Cymb	1	118
1341	Reverse BD	Cymb	1	119
1342	HiHat Open 1/2	Cymb	1	120
1343	Cym. Crash NL	Cymb	1	121
1344	Cym. O. s (1)	Cymb	48	121
1345	Cym. Ride NL	Cymb	1	122
1346	Cym. O. s	Cymb	48	122
1347	Cym. Cup NL	Cymb	1	123
1348	Cy. O. m (1)	Cymb	48	123
1349	Cym. Splash NL	Cymb	1	124
1350	Cy. O. m	Cymb	48	124
1351	Reverse Cym.	Cymb	1	125
1352	Cy. . open(1)	Cymb	48	125
1353	Cy. O. op. (1)	Cymb	48	126
1354	Ride Cymbal	CYMBAL	48	30
1355	Crash Cymbal	CYMBAL	0	49
1356	Crash Cymbal 1	Cymbal	1	49
1357	808 Cym	CYMBAL	25	49
1358	Crash	CYMBAL	29	49
1359	Brush Crash	CYMBAL	40	49
1360	Tom High High EZ GMS	Cymbal	1	50
1361	Brush Tom	CYMBAL	40	50
1362	Ride Cymbal	CYMBAL	0	51
1363	Ride Cymbal 1 [Repetition"	Cymbal	1	51
1364	Ride	CYMBAL	29	51
1365	Brush Ride	CYMBAL	40	51
1366	China Cym	CYMBAL	0	52
1367	China Cymbal	Cymbal	1	52
1368	Crash	CYMBAL	29	52
1369	Brush China	CYMBAL	40	52
1370	Ride Cup	CYMBAL	0	53
1371	Ride Cup	Cymbal	1	53
1372	Ride cup	CYMBAL	29	53
1373	Brush Cup	CYMBAL	40	53
1374	Tambourin [Repetition]	Cymbal	1	54
1375	Splash Cym	CYMBAL	0	55
1376	Splash Cymbal	Cymbal	1	55
1377	Brush Splash	CYMBAL	40	55

Nummer	Instrument	Gruppe	Bank	Programm
1378	Cowbell	Cymbal	1	56
1379	Crash 2	CYMBAL	0	57
1380	Crash Cymbal 2	Cymbal	1	57
1381	Crash	CYMBAL	29	57
1382	Brush Crash 2	CYMBAL	40	57
1383	Orch. Cymbal 2	CYMBAL	48	57
1384	Vibraslap	Cymbal	1	58
1385	Ride Cymbal 2 [Repetition]	Cymbal	1	59
1386	Ride	CYMBAL	29	59
1387	Brush Ride 2	CYMBAL	40	59
1388	Orch. Cymbal 1	CYMBAL	48	59
1389	Konzert Becken	CYMBAL	29	88
1390	Konz. Becken 1	CYMBAL	29	89
1391	K.Becken stopp	CYMBAL	29	90
1392	K.Becken offen	CYMBAL	29	91
1393	K.Becken 1/2a	CYMBAL	29	92
1394	K.Becken 1/2b	CYMBAL	29	93
1395	E-Snare	E-Snarr	1	89
1396	E-Snare	E-Snarr	1	90
1397	E-Snare	E-Snarr	1	91
1398	E-Snare	E-Snarr	1	92
1399	E-Snare	E-Snarr	1	93
1400	E-Snare	E-Snarr	1	94
1401	E-Snare	E-Snarr	1	95
1402	E-Snare	E-Snarr	1	96
1403	E-Snare	E-Snarr	1	97
1404	E-Snare	E-Snarr	1	98
1405	E-Snare	E-Snarr	1	99
1406	E-Snare	E-Snarr	1	100
1407	E-Snare	E-Snarr	1	101
1408	E-Snare	E-Snarr	1	102
1409	E-Snare	E-Snarr	1	103
1410	E-Claps	E-Snarr	1	104
1411	E-Claps	E-Snarr	1	105
1412	E-Claps	E-Snarr	1	106
1413	E-Claps	E-Snarr	1	107
1414	E-Claps	E-Snarr	1	108
1415	Zap	FX	0	15
1416	Whip Slap	FX	0	16
1417	Scratch	FX	0	17
1418	Scratch	FX	0	18
1419	Applaus	FX	48	88
1420	Git FX 1	FX	0	97
1421	Rhythm Git FX 1	FX	40	97
1422	Git FX 2	FX	0	98
1423	Rhythm Git FX 2	FX	40	98
1424	Git FX 3	FX	0	99
1425	Rhythm Git FX 3	FX	40	99
1426	Git FX 4	FX	0	100
1427	Rhythm Git FX 4	FX	40	100
1428	Git FX 1 High P	FX	0	101

Nummer	Instrument	Gruppe	Bank	Programm
1429	R. Git FX 1 HP	FX	40	101
1430	Git FX 2 High P	FX	0	102
1431	R. Git FX 2 HiP	FX	40	102
1432	Git FX 3 High P	FX	0	103
1433	R. Git FX 3 HP	FX	40	103
1434	Git FX 4 High P	FX	0	104
1435	R. Git FX 4 HP	FX	40	104
1436	Klappengeräusch 1	FX	29	111
1437	Klappengeräusch 2	FX	29	112
1438	Klappengeräusch 3	FX	29	113
1439	Klappengeräusch 4	FX	29	114
1440	Luft	FX	29	115
1441	Löffel	FX	29	116
1442	Hi Hat closed	HIHAT	48	27
1443	Hi Hat Pedal	HIHAT	48	28
1444	Hi Hat Open	HIHAT	48	29
1445	Hi Hat Closed	HIHAT	0	42
1446	808 Hi Hat Cl.	HIHAT	25	42
1447	Hi hat closed	HIHAT	29	42
1448	Hi Hat Pedal	HIHAT	0	44
1449	808 Hi Hat Pe.	HIHAT	25	44
1450	Hi hat pedal	HIHAT	29	44
1451	Hi Hat Open	HIHAT	0	46
1452	808 Hi H. Op.	HIHAT	25	46
1453	Hi hat open	HIHAT	29	46
1454	Surdo Mute	Perc	1	13
1455	Surdo Open	Perc	1	14
1456	Hi Q	Perc	1	15
1457	Whipe Slap	Perc	1	16
1458	Scratch	Perc	1	17
1459	Scratch	Perc	1	18
1460	Finger Snap	Perc	1	19
1461	Click Noise	Perc	1	20
1462	Metronom Click	Perc	1	21
1463	Metronom Bell	Perc	1	22
1464	Seq. Click	Perc	1	23
1465	Seq. Click	Perc	1	24
1466	Brush Tap	Perc	1	25
1467	Brush Swirl	Perc	1	26
1468	Brush Slap	Perc	1	27
1469	Brush Tap Swirl	Perc	1	28
1470	Snare Roll	Perc	1	29
1471	Castagnet	Perc	1	30
1472	Snare soft LS Cravio	Perc	1	31
1473	Sticks	Perc	1	32
1474	Cabasa [Repetition]	Perc	1	69
1475	Maracas [Repetition]	Perc	1	70
1476	Whistle	Perc	1	71
1477	Whistle	Perc	1	72
1478	Guiro short	Perc	1	73
1479	Guiro long	Perc	1	74

Nummer	Instrument	Gruppe	Bank	Programm
1480	Claves	Perc	1	75
1481	Woodblock low	Perc	1	76
1482	Woodblock hi	Perc	1	77
1483	Cuica mute	Perc	1	78
1484	Cuica open	Perc	1	79
1485	Triangle mute (5)	Perc	1	80
1486	Triangle open (5)	Perc	1	81
1487	Shaker	Perc	1	82
1488	Jingle Bell	Perc	1	83
1489	Chimes	Perc	1	84
1490	Tamburin Hit 1	Perc	1	85
1491	Tamburin Hit 2	Perc	1	86
1492	Tamburin Hit 3	Perc	1	87
1493	Tamburin Hit 4	Perc	1	88
1494	Mute Surdo	PERCUSSION	0	13
1495	Open Surdo	PERCUSSION	0	14
1496	Finger Snap	PERCUSSION	0	19
1497	Click	PERCUSSION	0	20
1498	Clap	PERCUSSION	0	39
1499	Claps	PERCUSSION	29	39
1500	Castagnet	PERCUSSION	48	39
1501	Tambourin	PERCUSSION	0	54
1502	Tamburin	PERCUSSION	29	54
1503	Splash	PERCUSSION	29	55
1504	Cowbell	PERCUSSION	0	56
1505	808 Cowbell	PERCUSSION	25	56
1506	Cowbell	PERCUSSION	29	56
1507	Vibraslap	PERCUSSION	0	58
1508	Vibraslap	PERCUSSION	29	58
1509	Ride Cym 2	PERCUSSION	0	59
1510	Bongo H	PERCUSSION	0	60
1511	Bongo L	PERCUSSION	0	61
1512	Conga Mute	PERCUSSION	0	62
1513	808 Conga M.	PERCUSSION	25	62
1514	Conga Open	PERCUSSION	0	63
1515	808 Con. Op.	PERCUSSION	25	63
1516	Conga Low	PERCUSSION	0	64
1517	808 Con. Low	PERCUSSION	25	64
1518	Timbale H	PERCUSSION	0	65
1519	Timbale L	PERCUSSION	0	66
1520	Agogo H	PERCUSSION	0	67
1521	Agogo L	PERCUSSION	0	68
1522	Cabasa	PERCUSSION	0	69
1523	Cabasa elec.	PERCUSSION	25	69
1524	Maracas	PERCUSSION	0	70
1525	808 Maracas	PERCUSSION	25	70
1526	Sam. Whistle H	PERCUSSION	0	71
1527	Sam. Whistle L	PERCUSSION	0	72
1528	Guiro Short	PERCUSSION	0	73
1529	Guiro elec.	PERCUSSION	25	73
1530	Guiro Long	PERCUSSION	0	74

Nummer	Instrument	Gruppe	Bank	Programm
1531	Guiro elec.	PERCUSSION	25	74
1532	Claves	PERCUSSION	0	75
1533	808 Claves	PERCUSSION	25	75
1534	Woodblock L	PERCUSSION	0	76
1535	Woodblock H	PERCUSSION	0	77
1536	Cuica Mute	PERCUSSION	0	78
1537	Cuica Open	PERCUSSION	0	79
1538	Triangle Mute	PERCUSSION	0	80
1539	Triangle Open	PERCUSSION	0	81
1540	Shaker	PERCUSSION	0	82
1541	Shaker elec.	PERCUSSION	25	82
1542	Jingle Bell	PERCUSSION	0	83
1543	Bell Tree	PERCUSSION	0	84
1544	Castanet	PERCUSSION	0	85
1545	Zap	PERCUSSION	25	85
1546	Surdo Mute	PERCUSSION	0	86
1547	Surdo Open	PERCUSSION	0	87
1548	Snare 3	SNARE	29	20
1549	Stick H	SNARE	0	21
1550	Snare 4	SNARE	29	21
1551	Stick L	SNARE	0	22
1552	Snare 5	SNARE	29	22
1553	Stick L	SNARE	0	23
1554	909 SN1	SNARE	25	23
1555	Stick H	SNARE	0	24
1556	909 SN 2	SNARE	25	24
1557	Snare 6	SNARE	29	24
1558	Brush Tap	SNARE	0	25
1559	909 SN 3 hard	SNARE	25	25
1560	Snare 7	SNARE	29	25
1561	Brush Swirl	SNARE	0	26
1562	909 SN 3	SNARE	25	26
1563	Snare 8	SNARE	29	26
1564	Brush Slap	SNARE	0	27
1565	Snare 9	SNARE	29	27
1566	Brush Swirl2	SNARE	0	28
1567	Snare brush 1	SNARE	29	28
1568	Snare Roll	SNARE	0	29
1569	Snare brush 2	SNARE	29	29
1570	Castagnet	SNARE	0	30
1571	Snare brush 3	SNARE	29	30
1572	Snare Soft	SNARE	0	31
1573	Brush Snare 3	SNARE	40	31
1574	Stick	SNARE	0	32
1575	Snare Open	SNARE	0	34
1576	Rim	SNARE	0	37
1577	808 Rim	SNARE	25	37
1578	Rim	SNARE	29	37
1579	Snare 1	SNARE	0	38
1580	Hit Snare 1	SNARE	4	38
1581	Room Snare 1	SNARE	8	38

Nummer	Instrument	Gruppe	Bank	Programm
1582	Power Snare 1	SNARE	16	38
1583	Elec Snare 1	SNARE	24	38
1584	808 Snare 1	SNARE	25	38
1585	Snare 1 - velosp.	SNARE	29	38
1586	Jazz Snare 1	SNARE	32	38
1587	Brush Snare 1	SNARE	40	38
1588	Orchestra Snare	SNARE	48	38
1589	Snare 2	SNARE	0	40
1590	Hit Snare 2	SNARE	4	40
1591	Room Snare 2	SNARE	8	40
1592	Power Snare 2	SNARE	16	40
1593	Elec Snare 2	SNARE	24	40
1594	808 Snare 2	SNARE	25	40
1595	Snare 2 - velosp.	SNARE	29	40
1596	Jazz Snare 2	SNARE	32	40
1597	Brush Snare 2	SNARE	40	40
1598	Jazz Snare 2	SNARE	48	40
1599	Orchestra Snare	SNARE	48	41
1600	Kleine Trommel	SNARE	29	94
1601	Kleine Trommel	SNARE	29	95
1602	Kl.Tr. 1. Schlag	SNARE	29	96
1603	Kl.Tr. 2. Schlag	SNARE	29	97
1604	Kl.Tr. 3. Schlag	SNARE	29	98
1605	Kl.Tr. 4. Schlag	SNARE	29	99
1606	Kl.Tr. 1. S.Rim	SNARE	29	100
1607	Kl.Tr. 2. S.Rim	SNARE	29	101
1608	Kl.Tr. 3. S.Rim	SNARE	29	102
1609	Kl.Tr. 4. S.Rim	SNARE	29	103
1610	Kl. Tr. Rim	SNARE	29	104
1611	Kl. Tr. Flam	SNARE	29	105
1612	Kl. Tr. Flam	SNARE	29	106
1613	Kl. Tr. Flam	SNARE	29	107
1614	Kl. Tr. Wirbel 1	SNARE	29	108
1615	Kl. Tr. Wirbel 2 Akz	SNARE	29	109
1616	Kl. Tr. Wirbel 3	SNARE	29	110
1617	Rim MO	Snarr	48	17
1618	Snare MO	Snarr	48	18
1619	Rim MO	Snarr	48	19
1620	Snare MO	Snarr	48	20
1621	Snare MO	Snarr	48	22
1622	Snare MO	Snarr	48	23
1623	Snare MO	Snarr	48	24
1624	Sidestick LS Cravio	Snarr Clap Rimshot	1	37
1625	Snare LS Cravio	Snarr Clap Rimshot	1	38
1626	Clap	Snarr Clap Rimshot	1	39
1627	Snare Rimshot LS Cravio	Snarr Clap Rimshot	1	40
1628	Tom LL	TOM	0	41
1629	Tom Low Low EZ GMS	Tom	1	41
1630	Power Tom	TOM	4	41
1631	Power Tom	TOM	16	41
1632	Elec Tom	TOM	24	41

Nummer	Instrument	Gruppe	Bank	Programm
1633	808 Tom	TOM	25	41
1634	Tom LL	TOM	29	41
1635	Brush Tom	TOM	40	41
1636	HiHat closed (0)	Tom	1	42
1637	Timpani	TOM	48	42
1638	Tom L	TOM	0	43
1639	Tom Low EZ GMS	Tom	1	43
1640	Power Tom	TOM	4	43
1641	Power Tom	TOM	16	43
1642	Elec Tom	TOM	24	43
1643	808 Tom	TOM	25	43
1644	Tom L	TOM	29	43
1645	Brush Tom	TOM	40	43
1646	Timpani	TOM	48	43
1647	HiHat Pedal (0)	Tom	1	44
1648	Timpani	TOM	48	44
1649	Tom ML	TOM	0	45
1650	Tom Medium L. EZ GMS	Tom	1	45
1651	Power Tom	TOM	4	45
1652	Power Tom	TOM	16	45
1653	Elec Tom	TOM	24	45
1654	808 Tom	TOM	25	45
1655	Tom M	TOM	29	45
1656	Brush Tom	TOM	40	45
1657	Timpani	TOM	48	45
1658	HiHat open (0)	Tom	1	46
1659	Timpani	TOM	48	46
1660	Tom M	TOM	0	47
1661	Tom Medium EZ GMS	Tom	1	47
1662	Power Tom	TOM	4	47
1663	Power Tom	TOM	16	47
1664	Elec Tom	TOM	24	47
1665	808 Tom	TOM	25	47
1666	Tom MH	TOM	29	47
1667	Brush Tom	TOM	40	47
1668	Timpani	TOM	48	47
1669	Tom H	TOM	0	48
1670	Tom High EZ GMS	Tom	1	48
1671	Power Tom	TOM	4	48
1672	Power Tom	TOM	16	48
1673	Elec Tom	TOM	24	48
1674	808 Tom	TOM	25	48
1675	Tom H	TOM	29	48
1676	Brush Tom	TOM	40	48
1677	Timpani	TOM	48	48
1678	Timpani	TOM	48	49
1679	Tom HH	TOM	0	50
1680	Power Tom	TOM	4	50
1681	Power Tom	TOM	16	50
1682	Elec Tom	TOM	24	50
1683	808 Tom	TOM	25	50

Nummer	Instrument	Gruppe	Bank	Programm
1684	Tom H	TOM	29	50
1685	Timpani	TOM	48	50
1686	Ride 909	TOM	25	51
1687	Timpani	TOM	48	51
1688	Timpani	TOM	48	52
1689	Cup 66	TOM	25	53
1690	Timpani	TOM	48	53
1691	Tamb. 66	TOM	25	54
1692	Pauke C	TOM	29	60
1693	Pauke Cis	TOM	29	61
1694	Pauke D	TOM	29	62
1695	Pauke Es	TOM	29	63
1696	Pauke E	TOM	29	64
1697	Pauke F	TOM	29	65
1698	Pauke Fis	TOM	29	66
1699	Pauke G	TOM	29	67
1700	Pauke As	TOM	29	68
1701	Pauke A	TOM	29	69
1702	Pauke Bb	TOM	29	70
1703	Pauke H	TOM	29	71
1704	Pauke C	TOM	29	72
1705	Pauke Cis	TOM	29	73